

附录一 ASCII 码表

高位	000	001	010	011	100	101	110	111
十六进制	0	1	2	3	4	5	6	7
0000	0		SPACE	0	@	P		p
0001	1		!	1	A	Q	a	q
0010	2		"	2	B	R	b	r
0011	3		#	3	C	S	c	s
0100	4		\$	4	D	T	d	t
0101	5		%	5	E	U	e	u
0110	6		&	6	F	V	f	v
0111	7		[]	7	G	W	g	w
1000	8		)	8	H	X	h	x
1001	9		(	9	I	Y	i	y
1010	A		*	:	J	Z	j	z
1011	B		+	;	K	✓	k	{
1100	C		,	<	L	¥	l	
1101	D		-	=	M	π	m	}
1110	E		•	>	N	^	n	~
1111	F		/	?	O	—	o	■